## **BOLT HEAD SIZE CHART** FOR HEX, LAG AND SQUARE BOLTS

Use this chart to determine the head size, and therefore the wrench or socket size required, for any hex bolt, heavy hex bolt, lag screw or square bolt you're using.

| BOLT     | HEAD / WRENCH / SOCKET SIZE       |                |
|----------|-----------------------------------|----------------|
| DIAMETER | Hex Bolt / Lag Bolt / Square Bolt | Heavy Hex Bolt |
| #6       | 1/4"                              |                |
| #8       | 1/4"                              | ~              |
| #10      | 5/16"                             | 121            |
| #12      | 5/16"                             | ~              |
| 1/4"     | 7/16" or 3/8"                     | -              |
| 5/16"    | 1/2"                              | 5 <u>47</u>    |
| 3/8"     | 9/16"                             | . <del></del>  |
| 7/16"    | 5/8"                              | -              |
| 1/2"     | 3/4"                              | 7/8"           |
| 9/16"    | 13/16"                            | <u>s</u>       |
| 5/8"     | 15/16"                            | 1-1/16"        |
| 3/4"     | 1-1/8"                            | 1-1/4"         |
| 7/8"     | 1-5/16"                           | 1-7/16"        |
| 1"       | 1-1/2"                            | 1-5/8"         |
| 1-1/8"   | 1-11/16"                          | 1-3/4"         |
| 1-1/4"   | 1-7/8"                            | 2"             |

Need more information on diameters and head sizes? Just ask!

